




52.1



52.2

65

44




53.1



53.2




53.3



53.4




Adjustable cross clamp with support washer
This product may be used only as an intermediate rope guide (not as an end connector). Dimension **b1** corresponds to the distance between the wall and the inner wire rope.




No. 30836-




The user is responsible for choosing the correct assembly method and the proper rope diameter.



No. 30920-
0400-01





No. 30920-
0400-02




No. 30858-
0400

1.4404 / AISI 316




No. 30858-
0400-01

1.4404 / AISI 316



No. 30858-
0400-02


1.4404 / AISI 316



No. 30836-
b1

0044-40	44
0064-40	64
0084-40	84

1.4404 / AISI 316



No. 30920-
0400-03

1.4404 / AISI 316